




AIRES Foundation

www.Aires.fund


E-mail: foundation@aires.fund




AIRES CONVERTER



The sizes of the AIRES Converter



The stages of assembly of the AIRES Converter





The stages of assembly of the AIRES Converter





Perspective view

Top view

1



2





The stages of assembly of the AIRES Converter





Perspective view

Top view

3




4




The stages of assembly of the AIRES Converter



Top view



Perspective view



4



The stages of assembly of the AIRES Converter





Perspective view

Top view

5




6




The stages of assembly of the AIRES Converter



Top view



Perspective view




6


The stages of assembly of the AIRES Converter



Perspective view



Top view




7


The stages of assembly of the AIRES Converter



Perspective view




Top view




7


The stages of assembly of the AIRES Converter



The stages of assembly of the AIRES Converter




9



10




The stages of assembly of the AIRES Converter



11

The thickness of the sheets Aires Fender in the glass - 0.5 mm
The thickness of the sheets of Aires Fender in the reactor - 2 mm



* Aries reactor height - 0.85m



AIRES CONVERTER